

## Stool Collection Examples



A good example of the amount of sample needed. The sample is submerged within the preservative, ready for vigorous shaking.



Although this is a good amount of sample, the preservative liquid has been poured away.



Too much of the sample has been placed in the sample collection tube.



Although these look to be a correct sample. The tube lid has not been securely tightened or has been cross-threaded.